



INSTALLATION INSTRUCTIONS

APPLICATION:

2009-2013 Ford F-150

AUTOMOTIVE PRODUCTS,

PART NUMBER:

58-140915/58-14091R

CONTENT			
ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	4	1/2 x 1 1/2 in Bolt	3/4" SOCKET
2	6	1/2 x 3 1/2 in Bolt	10 MM SOCKET
3	10	1/2 in Nut	3/4" WRENCH
4	4	M8 - 1.25 X 14 MM CAP SCREW	18 MM WRENCH
			RATCHET WITH EXTENSIONS

REMOVAL

1. Unhook the factory fog light wires, if present
2. Remove the headlights
3. Remove the bolts that attach the plastic cowl to the fenders
4. Remove the bolts that attach the side braces to the inner fender
5. Remove the factory bumper by removing 4 nuts located on the frame horns (2 on each side)
6. Remove the factory tow hooks
7. Reinstall the bolts that were removed from the side braces to secure the inner fender

INSTALLATION

1. Attach the intermediate brackets to the frame using the 4 - 1/2" x 1 1/2" bolts and 4 - 1/2" nuts leaving hardware loose
2. Using the factory tow hook bolt and nut plate, secure the bottom side of the bracket to the frame
3. Align the bumper with the truck and intermediate brackets to install the 6 - 1/2" x 3 1/2" bolts and 6 - 1/2" nuts
4. Position the bumper to achieve proper alignment
5. Tighten all hardware



Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773

Thank You for choosing Westin products
For Additional installation assistance please call
Customer service (800) 793-7846

www.westinautomotive.com