



# INSTALLATION INSTRUCTIONS

APPLICATION:

2015 Chevy 2500/3500 HD

AUTOMOTIVE PRODUCTS, PART NUMBER:

58-151515/58-15151R

CONTENT			
ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	6	1/2" x 3 1/2" BOLT	15MM SOCKET
2	10	1/2" x 1 1/2" BOLT	18MM SOCKET
3	16	1/2" NUT	3/4" SOCKET
4	4	M-8 x 1.25 HEX HEAD CAP SCREW	3/4" WRENCH
			RATCHET

## REMOVAL

1. Remove the 12 plastic push pin connectors from the radiator cover.
2. Remove the screw from the inner fender well, then repeat for opposite side. (Image 1)
3. Remove the 8 bolts from the grill
4. Disconnect the fog light wiring harness plug, located inside the passenger frame rail. (Image 2)
5. Remove the bolts from the bumper side braces. (Image 3)
6. Remove the 8 bolts that attach the bumper to the frame.
7. Remove the bumper from the truck.
8. Remove the factory tow hooks.



Image 1



Image 2



Image 3



Westin Automotive Products, Inc.  
320 W. Covina Blvd  
San Dimas, Ca. 91773

Thank You for choosing Westin products  
For Additional installation assistance please call  
Customer service (800) 793-7846

## INSTALLATION

1. Align the frame brackets with the holes on the end of the frame horn and loosely install the 10 - 1/2" x 1 1/2" bolts and 1/2" nuts. (Image 4)
2. Lift the bumper and slide the mounts into the channels on the frame brackets.
3. Install the 6 - 1/2" x 3 1/2" bolts and 1/2" nuts into the frame brackets and mounts.
4. Adjust bumper to achieve proper alignment.
5. Tighten all hardware.



Image 4



Westin Automotive Products, Inc.  
320 W. Covina Blvd  
San Dimas, Ca. 91773

Thank You for choosing Westin products  
For Additional installation assistance please call  
Customer service (800) 793-7846  
[www.westinautomotive.com](http://www.westinautomotive.com)