



# INSTALLATION INSTRUCTIONS

APPLICATION:

2007-2012 Toyota Tundra

AUTOMOTIVE PRODUCTS, PART NUMBER:

58-170715/58-17071R

CONTENT			
ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	6	1/2" X 3 1/2" BOLT	10MM SOCKET
2	6	1/2" NUT	17MM SOCKET
3	4	M8 - 1.25 X 14 MM CAP SCREW	3/4" SOCKET
			14MM WRENCH
			RATCHET

## REMOVAL

1. Remove the plastic clip and the 2 Philips head screws from each inner fender
2. Remove the 3 screws from the bottom plastic on the bumper
3. Disconnect the factory fog lights
4. Remove the factory tow hooks
5. Remove the 8 nuts that attach the bumper to the frame
6. Remove the factory bumper
7. Remove the painted plastic trim pieces located just below the headlights
8. Remove the plastic valance
9. Remove the plastic filler pieces that attach the valance to the fender

## INSTALLATION

1. Attach the intermediate brackets to the frame using the factory hardware, leaving the hardware loose
2. Align the bumper with the truck and intermediate brackets and install the 6 - 1/2" x 3 1/2" bolts and 1/2" nuts
3. Position the bumper to achieve proper alignment
4. Tighten all hardware



Westin Automotive Products, Inc.  
320 W. Covina Blvd  
San Dimas, Ca. 91773

Thank You for choosing Westin products  
For Additional installation assistance please call  
Customer service (800) 793-7846