5

6

7

8

2

8

4

4

INSTALLATION INSTRUCTIONS 2003/2006 CHEVROLET GMC SILVERADO 1500,2500LD

	Parts list					Required tools (not included)	
Ítem	Qty.	Códe	Description	Max. Torque	Qty	Description	
	1	BRK-520765	Brackets kit:		1	socket/wrench 5/8"	
1	1		Set of Principal Brackets		1	socket / wrench 11/16"	
2	4		Rod bolt 7/16"		1	socket / wrench 3/4"	
					1	ratchet extension	
	1	KTE-520765	hardware kit:		1	ratchet	
3	2		Hex.head bolt 1/2" x 1 1/2"				
4	4		Flat washer 1/2"			llustración de Brackets	



Instrucciones

1. Read and understand instructions completely before beginning installation.

Lock washer 1/2"

Flat washer 7/16"

Nut 7/16"

Lock washer 7/16"

2. To maintain and care this product keep it clean and do not use abrasive cleaners or waxes. We recommend to use only non-abrasive automotive wax as pure carnauba, to avoid scratches and rust.

3. Remove dragging hooks from the chassis and keep the hook as the screws, these will not be re-installed **Note:** if vehicle does not have dragging hook's holes, you will have to cut as shown.

- 3 The energy installation time is 35 min
- 4. Once you remare the hooks, place the 7/16" hex head bolt inside the holes where you remove the hooks



ROD BOLT



MAIN MOUNTING BRACKETS

5. In the hooks place, put the mounting bracket, see picture 1, hold it with the bolts. Repeat this steps in the passenger side. **photo 3,4,5,6**.



PICTURE 5

PICTURE 3

DRIVER SIDE



PICTURE 4



PICTURE 6

PASSENGER SIDE



- 6. Hold on the dakar to the brackets with the 1/2" hardware kit.
- 7. Align the Dakar with the front of vehicle and tighten all nuts and bolts.
- 8. Fill out the warranty card and place it inside your vehicle's glove box.