



**Installation Instructions**  
Light Bar and Pre-Runner  
06-13 Chevrolet Tahoe, Suburban,  
Avalanche (6-lug ONLY)  
Models: C063LB, C063LH



*This installation uses existing Original Equipment (O.E.) hardware. No additional hardware is included.*

**Recommended Tools:**      Socket Set  
   Torque Wrench

Step 1: Locate the O.E. tow hooks through access holes in the front valance.

Step 2: Remove tow hook fasteners and tow hooks, and retain both for use in step 4.

Step 3: Position N-FAB Light Bar (Pre-Runner) brackets so that the mounting holes line up with the O.E. tow hook mounting holes.

Step 4: Position the driver's side tow hook in its original orientation, over the Light Bar (Pre-Runner) mounting bracket, and loosely reinstall O.E. mounting bolts. Repeat this step for passenger's side.

Step 5: Tighten O.E. tow hook bolts to 15 FT LB to complete installation.

Products Licensed to N-FAB Inc. by Fichter Designs are protected by US Patent Law and International Copy Right Law. Protected Patents include US Patent #6588783, #6874801, #7416202. Other patents and continuances pending. N-FAB product configurations also protected by International Trade Dress Law. All Designs and Patent infringements will be prosecuted to the full extent of the law.

---

For Technical Support, Please Call 281-880-6322  
N-FAB Inc., 12302 Shiloh Church Rd., Houston, TX 77066