#### INSTALLATION GUIDE

# RESERRCH POWErStep

APPLICATION

MODEL YR

AMP PART #

75101-01A

75101-01A

75118-01A

 Dodge Ram Quad Cab
 1500
 2002 - 2008

 Dodge Ram Quad Cab
 2500/3500
 2003 - 2009

 Dodge Ram Mega Cab
 2006 - 2009

INSTALLATION TIME 3-5 Hours Professional installation recommended SKILL LEVEL 4= Experienced **TOOLS REQUIRED** Safety goggles □ Measuring tape □ Flat blade screwdriver Phillips head screwdriver Right angle drill □ 1/8" drill bit 13 mm socket Ratchet wrench and extension Soldering iron □ Wire crimpers U Wire stripper / cutter Corrosion inhibiter □ 3/16" hex key wrench (allen wrench ) □ 1/8" hex key wrench (allen wrench) □ 4 mm hex key wrench (allen wrench ) Pop rivet tool Electrical tape WARRANTY 5-Year Limited Warranty AMP RESEARCH TECH SUPPORT 1-888-983-2204 (Press 2) Monday - Friday, 7:00 AM - 5:00 PM PST Invented, engineered and manufactured exclusively by AMP Research in the USA. May be covered by one of the following patents: 6,641,158; 6,830,257; 6,834,875; 6,938,909; 7,055,839; 7,380,807; 7,398,985; 7,584,975 ©2012 AMP Research. All rights reserved. Printed in USA.

www.amp-research.com

IM75101 rev 12.18.19

## INSTALLATION GUIDE Attaching motor to linkage assembly

The motors need to be installed before continuing with the rest of the Power Step install.



Instructions:

1. Position the gear cover in place as shown if not already in place.

2. Seat motor into position on the three mounting bosses. This may require an adjustment of the gear by moving the swing arms.

3. After seating into place, fasten the motor with the three motor mount screws with 4mm Hex Head. Tighten screws to 36 in-lbs (4N-m). **Do not over torque.** 









#### AMP RESEARCH POWERSTEP<sup>TM</sup> - DODGE RAM





#### AMP RESEARCH POWERSTEP<sup>™</sup> - DODGE RAM



www.amp-research.com



#### AMP RESEARCH POWERSTEP<sup>™</sup> - DODGE RAM



#### AMP RESEARCH POWERSTEP™ - DODGE RAM

Check that all doors activate the Power Step and the LED Lights work when doors open and close. Reinstall any remaining trim panels.



#### FINAL SYSTEM CHECK

Check that all doors activate the PowerStep and the LED lights work when doors open and close. **NORMAL OPERATION:** When the doors open, PowerStep automatically deploys from under the vehicle. When the doors are closed, PowerStep will automatically return to the stowed/retracted position. **Note that** *there is a 2-second delay before the PowerStep returns to the stowed/retracted position.* **CORRECT OPERATION OF LIGHTS:** All four lamps will illuminate upon opening any door of vehicle. Lamps will stay on until restowing of both Power Steps or until 5 minutes has expired with the doors open. When the lights timeout after 5 minutes, they can be reillumintated by closing and opening any door of vehicle.

# Congratulations on the purchase of your AMP Research Power Step

# **АПТР** РОШег Step

Here's what you should know...

#### OPERATION

The AMP Research Power Step automatically deploys when at least one door opens and automatically retracts under your vehicle when both front and rear doors close. If resistance or blockage is encountered while the Power Step is in motion, the drive system is designed to automatically stop. To reset, simply open or close the vehicle door and the Power Step will resume normal operation.

#### **MAINTENANCE TIPS**

The stepping surface and drive mechanism can be washer with mild soap and water using a soft brush or sponge to dislodge any mud, dirt or accumulated road grime. Rinse with fresh water.

To prevent slipping, avoid applying waxes, lubricants or protectants like Armor All® to the step surface.

When washing your vehicle, the Power Steps can be set to remain deployed with the doors closed for easy cleanning. Do this...

1 With the Power Step deployed, press and hold the board down with your foot.

2 Close the door while continuing to press down the board. (This will not harm motor.)

**3** To reset the Power Step, simply open and close the door. (Repeat for both sides of vehicle.)

CAUTION! BE SURE TO KEEP HANDS AWAY WHEN THE POWER STEP IS IN MOTION.

amp-research.com

#### LIMITED WARRANTY

AMP RESEARCH warrants product to be free from defects in material and workmanship, for terms specified below, provided there has been normal use and proper maintenance. This warranty applies to the original purchaser only. All remedies under this warranty are limited to the repair of replacement of any item found by the factory to be defective within the time period specified.

If you have a warranty claim, first you must call our factory at the number below for instructions. You must retain proof of purchase and submit a copy with any items returned for warranty work. Upon completion of warranty work, if any, we will return the repaired or replaced item or items to you freight prepaid. Damage to our products caused by accidents, fire, vandalism, negligence, misinstallation, misuse, Acts of God, or by defective parts not manufactured by us, is not covered under this warranty.

THE WARRANTY TIME PERIOD IS AS FOLLOWS: THREE YEARS FROM DATE OF PURCHASE.

ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR PURPOSE CREATED HEREBY ARE LIMITED IN DURATION TO THE SAME DURATION AND SCOPE AS THE EXPRESS WRITTEN WARRANTY. OUR COMPANY SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGE.

Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

FOR WARRANTY ISSUES WITH THIS PRODUCT PLEASE CALL AMP RESEARCH CUSTOMER SERVICE 1-888-983-2204

### WARNING

Be sure to read and precisely follow the provided instructions when installing this product. Failure to do so could place the vehicle occupants in a potentially dangerous situation. After installing or reinstalling, re-check to insure that the product is properly installed.