



Congratulations on choosing the finest interior flooring kit available for your Jeep.
The BedRug/BedTred material is mold and mildew resistant, easily cleaned with water & household cleaning chemicals and extremely resistant to most chemicals.

Please retain these instructions for future reference in your vehicles glove box

- Kit Contents: Driver side rear sidewall, passenger side rear sidewall, rear floor, tailgate piece, hook fastener, J-clip, adhesive promoter, instruction sheet.
 2-DOOR REAR KIT
- Tools needed: Utility knife or scissors, soap, water, and rubbing alcohol.

NOTE: If front kit has been purchased, it is recommended to install the front kit first.



DON'T REMOVE YOUR FRONT SEATS!

Our kits and your factory carpet are precut to make removing your seats unnecessary.



PREPARATION

- 1. Read all instructions before beginning installation.
- 2. Remove rear bench seat and all flooring material (if equipped).
- 3. Thoroughly wash and dry areas where hook fastener will be applied.
- **4.** Cut the hook fasteners with tape backing to match the lengths of the loop sewn on the underside of each BedRug/BedTred piece. Cut the longest pieces first.
- 5. Place the hook fasteners on each matching piece of loop sewn on the back side of each BedRug/BedTred piece. **DO NOT REMOVE TAPE BACKING AT THIS TIME!**

IMPORTANT: Jeep floor should be at least 68°F (20°C) for maximum adhesion. Clean all areas with rubbing alcohol before applying tape. When removing backing, do not touch adhesive.

BEDRUG, INC. = 528 Myatt Dr, Madison, TN 37115 = 800-462-8435 = bedrug.com

BR-BTJL18R2INST Rev. 1 3/27/2019 Page 1 of 4



Jeep Wrangler JL Bedrug/BedTred Install Instructions



INSTALLING REAR FLOOR

- 6. Place the rear floor section into place. Tuck the liner around and underneath the front seat brackets and center console. (Fig. 1 & Fig. 2)
- 7. Once properly in place, pull back part to access the two pieces of hook fastener. Clean surface between rear seat latches (**Fig. 3**) with alcohol then remove the film backing and roll the part back into place. Firmly press the top surface to ensure adhesive attachment.







FIGURE: 2 FIGURE: 3

FITMENT NOTE: The rear floor section is designed to fit on top of the rear wheel well pieces.

8. Clean J-clip with alcohol and apply adhesive promoter to the J-clip. (**Fig. 4**) Peel off tape backing and apply matching length of hook fastener to J-clip. Slide J-clip onto edge of rear compartment lid and align J-clip with rear floor. (**Fig. 5**) Pull compartment handle through slit in floor piece and firmly press floor onto hook fastener to secure floor to J-clip. (**Fig. 6**)







FIGURE: 4 FIGURE: 5 FIGURE: 6

9. Clean rear floor trim with alcohol and apply adhesive promoter. (**Fig. 7**) Peel off tape backing from hook fastener and press rear piece to rear floor trim. (**Fig. 8**) Repeat on other side.





BEDRUG, INC. = 528 Myatt Dr, Madison, TN 37115 = 800-462-8435 = bedrug.com

BR-BTJL18R2INST Rev. 1 3/27/2019 Page 2 of 4



Jeep Wrangler JL Bedrug/BedTred Install Instructions



INSTALLING TAILGATE PIECE

10. Using alcohol, clean top and bottom areas of inside tailgate trim surface where hook fastener will be applied, and apply adhesive promoter to tailgate trim. Remove tape backing from fastener, align tailgate piece to tailgate, and attach to the tailgate. Firmly rub entire surface to ensure good attachment. (Fig. 9 and Fig. 10)





FIGURE 9:

FIGURE 10:

BR-BTJL18R2INST Rev. 1 3/27/2019 Page 3 of 4



The use of front floor mats is not recommended with BedRug or BedTred floor kits. If floor mats are used, it is imperative to re-use the removable retention hooks from the factory carpet, installed to the manufacturer's specifications. Do not use floor mats or liners with BedTred Kits. Do not use floor mats or liners with BedRug Kits without retention hooks.

Please retain these instructions for future reference in your vehicle's glove box

BEDRUG[®] BEDTRED[™] CLEANING INFORMATION

The mildew resistant BedRug/BedTred foam will not absorb liquids. The engineered composite surface resists stains and deterioration from most acids, chemicals, gas and oils, etc. Therefore, by following the cleaning instructions below, your BedRug/BedTred will remain serviceable for as long as you own your vehicle.

Cleaning your BedRug is easy:

- 1. A vacuum, broom, brush or compressed air can be used to remove dirt, grime, sand, mulch etc. Due to the fact that water will not harm the product, pressure washing is also an effective way to clean a soiled BedRug/BedTred.
- 2. Although most acids will not harm the BedRug/BedTred, baking soda should be applied immediately to neutralize the acid to ensure the safety of the paint on the vehicle.
- 3. To clean tougher jobs such as gasoline, oil, chemicals, acid spills or leaks from your BedRug/BedTred use detergent soap with degreaser and water, then rinse thoroughly. This detergent soap is used in most car wash locations with pressure washing equipment. The polypropylene closed-cell foam will not absorb water and the composite surface dries in minutes.

If you have additional questions, call BedRug Inc. customer service at 800-462-8435.

LIMITED WARRANTY

BedRug Inc. warrants BedRug and BedTred products for Jeep vehicles for three years from the original date of purchase. Warranty is limited to the original purchaser and is not transferable. Product is warranted to be free from defects in materials and workmanship. The warranty is void if the product has been damaged by accident, unreasonable use, neglect, improper service/installation/removal, modifications, acts of God, normal wear and tear, or other causes not arising out of defective materials or workmanship. Consequential and incidental damages are not covered under this warranty. Warranty does not cover labor, the cost of shipping, or cost of returning the product for warranty service or inspection. The terms of this warranty may vary from state to state. You may have rights under specific state laws that differ from the terms of this warranty. Proof of purchase will be required for warranty service. Product should be cleaned before return. A return authorization number must be obtained prior to returning any product. For warranty instructions, returns, and packaging contact BedRug Inc. Customer Service at 800-462-8435.

PRODUCT REGISTRATION

Thank you for purchasing your BedRug product! We would appreciate it if you would take a few minutes to register your purchase. Registration allows us to provide, with your permission, important updates, service information, helpful hints or warranty service should you ever require technical support. BedRug offers the option of returning product registration forms electronically, rather than having to fill them out by hand. You can be assured that BedRug does not share or sell the information you provide. Save a copy of your sales receipt. Activate your warranty by registering your product online at http://www.bedrug.com/customer-service/product-registration.html or by scanning the QR code. You will need the 6-digit lot and date code found on the underside of the tailgate, see label example below.





BR-BTJL18R2INST Rev. 1 3/27/2019 Page 4 of 4